




Assembly instructions
Notice de montage
Montage instructies
Montageanleitung
Istruzioni di montaggio
Instrucciones de montaje
Инструкция по сборке
Instrukcje montażu




PARTS AND TOOLS LIST


NO	Name	Qty
1	Lifting column	2
2	Bottom frame	1
3	Deckboard	1
4	Bottom metal plate	1
5	Caster	4
6	Keyboard tray	1
7	TV fixing holder	1
8	TV bracket	2
9	Bracket	2
10	Control box	1
11	Handset	1
12	M6*30 Screw	2
13	M6*14 Screw	8
14	M6*16 Screw	12
15	M4*12 Screw	4
16	ST4.8*13 Screw	4
17	4mm Hex Spanner	1
18	2.5mm Hex Spanner	1
19	Remote control octagonal box	1
20	Gyro octagonal box	1
21	Remote control box	1



STEP 1




M6*16 SCREW 12PCS




4MM HEX SPANNER






Gyro octagonal box


The handset is only used as an auxiliary control, while the remote control is the main control method. When there is no remote control, the handset can be used for control.



STEP 4




M4*12 SCREW 4PCS




2.5MM HEX SPANNER






ST4.8*13 SCREW




ST4.8*13 SCREW 4pcs




STEP 7




STEP 8



Gyro octagonal box




M6*14 SCREW 8PCS




4MM HEX SPANNER






4MM HEX SPANNER





Remote control box



M6*30 SCREW 2PCS

4MM HEX SPANNER

